

EEC269A - Error Correcting Codes I

Project Report

Chenyue Yang, Pranav Kharche, Parisa Oftadeh

June 5, 2023

Contents

1 Workload	2
2 Source & Destination	2
2.1 Source	2
2.1.1 Text string	2
2.1.2 Image	2
2.1.3 Audio	4
2.2 Destination	6
3 Channel	6
3.1 Binary Symmetric Channel (BSC)	6
3.2 Additive White Gaussian Noise (AWGN) Channel	6
4 (7,4) Systematic Linear Block (Hamming) Code	6
4.1 Syndrome Decoder	6
4.1.1 Text string	6
4.1.2 Image	7
4.1.3 Audio	7
5 (n, k) Systematic Cyclic (Hamming) Code	7
5.1 Syndrome Decoder	7
5.1.1 Text string	7
5.1.2 Image	7
5.1.3 Audio	7
5.2 LFSR Decoder	7
6 Appendix: Python source code	8
6.1 Source	8
6.2 Channel	15
6.3 Destination	20
6.4 Utilities	24
6.5 Linear code	28
6.6 Cyclic code	31

1 Workload

Table 1: Workload

Function	Workload	Contributor
Source	Text string (TXT), Image (PNG), Audio (WAV)	Chenye
Encoder	(7, 4) Systematic Linear Block (Hamming) Code	Chenye
	(n, k) Systematic Cyclic (Hamming) Code	Pranav, Chenye
Channel	Binary Symmetric Channel (BSC), error probability p adjustable	Chenye
	AWGN	Parisa
Error Corrector	Syndrome Lookup Table for (7, 4) Linear Code	Chenye
	Syndrome Lookup Table for (n, k) Cyclic Code	Chenye
	LFSR for (n, k) Cyclic Code	Pranav
Decoder	(7, 4) Systematic Linear Block (Hamming) Code	Chenye
	(n, k) Systematic Cyclic (Hamming) Code	Chenye
Destination	Text string (TXT), Image (PNG), Audio (WAV)	Chenye
Advanced features	Create generator matrix for (n, k) cyclic code	Pranav
	Adjustable (n, k)	Pranav
Presentation	Slides	Parisa
Report	Written by contributors	-

2 Source & Destination

2.1 Source

2.1.1 Text string

The very basic function of the information source is to read a hard-coded text file into a bit stream. In our text file, the following string is stored in ASCII format:

```
Hello World!
EEC269A Error Correcting Code Demo
```

In ASCII format, each character is represented by 8 bits, shown in Table 2. Then, after transformation, the bit stream is of size 376 bits:

```
0 1 0 0 1 0 0 0 0 1 1 0 0 1 0 1 ...
```

2.1.2 Image

PNG (Portable Network Graphics) is a raster graphics file format that supports lossless data compression. PNG supports a large number of colors (up to 16 million), as well as variable transparency, which makes it useful for images with varying degrees of transparency or opacity. Additionally, because PNG is a lossless

Table 2: ASCII Table example

Character	Hexadecimal	Decimal	Binary
...
A	41	65	0 1 0 0 0 0 0 1
B	42	66	0 1 0 0 0 0 1 0
C	43	67	0 1 0 0 0 0 1 1
D	44	68	0 1 0 0 0 1 0 0
E	45	69	0 1 0 0 0 1 0 1
F	46	70	0 1 0 0 0 1 1 0
G	47	71	0 1 0 0 0 1 1 1
H	48	72	0 1 0 0 1 0 0 0
...

format, it preserves all the detail in the original image, which is not the case with lossy formats like JPEG. It is used for the storage and display of images on the internet, and is also used in graphic design and editing applications due to its lossless compression.

PNG files consist of a header followed by a series of data chunks, e.g.:

1. Signature: The first eight bytes of a PNG file always contain the following decimal numbers: 137, 80, 78, 71, 13, 10, 26, 10. This signature indicates that the file is a PNG.
2. Header Chunk (IHDR): The first chunk after the signature is the IHDR chunk, which contains basic information about the image, such as width, height, bit depth, color type, compression method, filter method, and interlace method.
3. Palette Chunk (PLTE): This chunk is optional and only present for color type 3 (indexed color). It contains the color palette for the image.
4. Data Chunks (IDAT): These chunks contain the actual image data, which is formed by pixels. This data is compressed to reduce the size of the file.
5. End Chunk (IEND): This is the final chunk in a PNG file. It does not contain any data and its purpose is to indicate the end of the file.

Each chunk contains three standard fields: 4-byte length, 4-byte type code, 4-byte CRC and various internal fields that depend on the chunk type, shown in Figure 1. For example, the image file we are using has more than one image data (IDAT) chunks, each of which contains a portion of the image, shown in Table 3.

Ideally, the entire image file should be read into a bit stream and transmitted through the channel. However, if there are uncorrectable errors in the chunks other than the image data (IDAT), the received image will not be able to display. Therefore, we shall only work with the image data (IDAT) chunks for the purpose of visualization of a corrupted image. Also, this trick will not affect the statistical analysis of the system.

The information source is able to only extract the color information from a PNG file and convert it into a bit stream to be passed through the channel. This is done by using the Python library *NumPy*.

The library *NumPy* provides a method to only read out the color information of an image. The shape of the result array is typically *(height, width, channels)*, where:

1. *height* is the number of pixels in the vertical direction (i.e. the number of rows of pixels);
2. *width* is the number of pixels in the horizontal direction (i.e. the number of columns of pixels);
3. *channels* is the number of color channels per pixel. This value depends on what type of image it is:
 - In an RGB image, the three channels correspond to Red, Green, and Blue, respectively. Each channel value usually ranges from 0 to 255, where 0 indicates none of that color is present and 255 indicates that color is fully present.




Figure 1: PNG file structure



Figure 2: Our testing PNG image

- In a grayscale image, there is typically only one channel. The value in this single channel indicates the level of gray, where 0 is black and 255 is white.
- There are many other color spaces that have different meanings for their channels.

The data type for each channel of each pixel is *uint8*, which is an unsigned integer that takes 8 bits. Then, the array is flattened into a bit stream by converting each channel of each pixel into an 8-bits binary number and appending them together.

For example, as for our testing image¹, shown in Figure 2, the shape of the result array is $(1280, 854, 3)$, which means that the image has 1280 rows of pixels, 854 columns of pixels, and 3 color channels per pixel (RGB). Then, the array is flattened into a bit stream of 26,234,880 bits.

2.1.3 Audio

WAV (Waveform Audio File Format) is a digital audio standard for storing audio bitstream on PCs. WAV is an application of the Resource Interchange File Format (RIFF) method for storing data in chunks, and it is primarily used on Windows systems. WAV files are typically used for raw and uncompressed audio, though they can also contain compressed audio. A WAV file is divided into several sections or chunks, shown in Figure 3. Each chunk serves a different purpose and holds different types of data. The basic structure of a WAV file includes the following chunks:

1. RIFF Chunk: The RIFF chunk is the first chunk in a WAV file and identifies the file as a WAV file. It includes a header with the "RIFF" identifier and an integer indicating the remaining length of the entire file.
2. Format Chunk: Also known as the "fmt " chunk (with a space after 'fmt'), this contains important information about the audio data. This includes the audio format (e.g., PCM), the number of channels (mono, stereo, etc.), the sample rate, the byte rate, the block alignment, and the bit depth (bits per sample).

¹The image file used in this project is photographed by *Chenyen Yang*. The material is free from any copyright restrictions and can be used without any potential legal implications.

Table 3: Our PNG file structure

Start offset	Chunk outside
0	Special: File signature; Length: 8 bytes
8	Data length: 13 bytes; Type: IHDR; Name: Image header; CRC-32: CB3954EC
33	Data length: 1 bytes; Type: sRGB; Name: Standard RGB color space; CRC-32: AECE1CE9
46	Data length: 976 bytes; Type: eXIf; Name: Exchangeable Image File (Exif) Profile; CRC-32: 47FCFA4D
1,034	Data length: 9 bytes; Type: pHYs; Name: Physical pixel dimensions; CRC-32: 5024E7F8
1,055	Data length: 4 514 bytes; Type: iTxt; Name: International textual data; CRC-32: C9C76B16
5,581	Data length: 16 384 bytes; Type: IDAT; Name: Image data; CRC-32: 8462CABD
21,977	Data length: 16 384 bytes; Type: IDAT; Name: Image data; CRC-32: 2C9D007C
...	...
1,727,161	Data length: 12 170 bytes; Type: IDAT; Name: Image data; CRC-32: 68067F52
1,739,343	Data length: 0 bytes; Type: IEND; Name: Image trailer; CRC-32: AE426082

3. Data Chunk: This is where the actual audio data is stored. The "data" header is followed by an integer representing the length of the data, and then by the raw audio data itself.

Similar to the image file, the information source is able to only extract the audio Data Chunk from a WAV file and convert it into a bit stream to be passed through the channel. This trick ensures both the visualization of the results and the statistical analysis of the system. The extraction is done by using the Python library *soundfile*.

The library *soundfile* provides a method to only read out the audio data from a WAV file. The result contains two parts:

1. audio array: This is a *NumPy* array that contains the audio data from the file. The shape of the array depends on the number of channels in the audio file. If the audio is mono, the array will be one-dimensional. If the audio is stereo, the array will be two-dimensional, with one sub-array for each channel. The values in the array represent the amplitude of the audio signal at each sample point, and are of the data type specified.
2. sample rate: This is an integer that represents the number of samples per second in the audio file, measured in Hertz (Hz). Common sample rates include 44100 Hz (standard for audio CDs), 48000 Hz (standard for video production and DVDs), and 96000 Hz (used in high-definition formats).

Then, the *int16* array is "viewed" as *uint8* array by *numpy.view()* and flattened into a bit stream by converting each sample into an 8-bits binary number and appending them together. Note that the *numpy.view()* operation simply reinterprets the binary data, and does not convert or scale the data, which originally could be negative or positive.

For example, as for our testing audio file², shown in Figure 4 and Figure 5, the shape of the result audio array is (268237, 2) and the sample rate is 8000 Hz. It means that the 33.5-second audio file has 268237 samples per channel, and there are two channels (stereo). Then, the array is flattened into a bit stream of 8,583,584 bits.

²The audio file used in this project is free downloaded from file-examples.com. The material is free from any copyright restrictions and can be used without any potential legal implications.

The Canonical WAVE file format




Figure 3: Canonical WAV file structure

2.2 Destination

At the destination, the bit stream is re-construed into the original format, and stored. It is inevitable that some metadata is lost when processed by the system, since they are not transmitted through the channel. For example, the re-constructed image file will not have the camera and lens information. However, this is the trade-off for a better visualization, and will not affect the statistical analysis of the system.

3 Channel

3.1 Binary Symmetric Channel (BSC)

3.2 Additive White Gaussian Noise (AWGN) Channel

4 (7,4) Systematic Linear Block (Hamming) Code

4.1 Syndrome Decoder

4.1.1 Text string

Table 4: Text string encoded with Linear Hamming passed through BSC

Original	Without correction	Corrected
Hello World! EEC269A Error Correcting Code Demo	Hello Wopld! EEC269A Arror Correcting Kode Demo	Hello World! EEC269A Error Correcting Code Demo




Figure 4: Time domain waveform of our testing audio file




Figure 5: Frequency domain waveform of our testing audio file

4.1.2 Image

4.1.3 Audio

5 (n, k) Systematic Cyclic (Hamming) Code

5.1 Syndrome Decoder

5.1.1 Text string


Table 5: Text string encoded with Cyclic Hamming passed through BSC

Original	Without correction	Corrected
Hello World! EEC269A Error Correcting Code Demo	H <u>u</u> ,lo World! EEC269A Error Correctifg Code Demo	Hello World! EEC269A Error Correcting Code Demo

5.1.2 Image

5.1.3 Audio

5.2 LFSR Decoder



(a) Original

(b) Without correction

(c) Corrected

Figure 6: Image encoded with Linear Hamming passed through BSC (entire)


6 Appendix: Python source code

6.1 Source

```

1 # Copyright (c) 2023 Chenye Yang
2
3 import numpy as np
4 from PIL import Image
5 import soundfile as sf
6 # from scipy.io import wavfile
7 import logging
8

```



(a) Original

(b) Without correction

(c) Corrected

Figure 7: Image encoded with Linear Hamming passed through BSC (details)




Figure 8: Audio encoded with Linear Hamming passed through BSC

```

9  # Create a logger in this module
10 logger = logging.getLogger(__name__)
11
12
13 class Source:
14     """
15     The data source
16     """
17
18     def read_txt(self, src_path):
19         """
20             Read the text file as binary bits
21
22             @type src_path: string
23             @param src_path: source file path, with extension

```





Figure 9: Audio encoded with Linear Hamming passed through BSC

```

24     """
25     with open(src_path, 'rb') as file:
26         byte_array = bytearray(file.read())
27         self._digital_data = np.unpackbits(np.frombuffer(byte_array, dtype
28                                         =np.uint8))
29
30     def read_png(self, src_path):
31         """
32             Read the png file,
33             store the color information as binary bits in _digital_data,
34             store the color information as ndarray in _analogue_data.
35             Return the height, width, channels of the image.
36
37         @type  src_path: string

```



) Original (b) Without correction (c) Correc

```
38     @param src_path: source file path, with extension
39
40     @rtype: tuple
41     @return: height, width, channels
42     """
43
44     # Open the image file
45     image = Image.open(src_path)
46
47     # Convert the image to a NumPy array
48     img_array = np.array(image)
49
50     # Get the shape of the array (height, width, channels)
```




Figure 11: Image encoded with Cyclic Hamming passed through BSC (details)




Figure 12: Audio encoded with Cyclic Hamming passed through BSC

```

50     height, width, channels = img_array.shape
51
52     # Convert the img_array to binary format and flatten the array
53     bits = np.unpackbits(img_array.astype(np.uint8))
54
55     # Store the binary bits
56     self._digital_data = bits
57     # Store the analogue data
58     self._analogue_data = img_array
59
60     return height, width, channels
61
62
63     def read_wav(self, src_path):
64         """

```




Figure 13: Audio encoded with Cyclic Hamming passed through BSC

```

65     Read the wav file ,
66     store the audio information as binary bits in _digital_data ,
67     store the audio information as ndarray in _analogue_data .
68     Return the frame_rate , sample_width , channels of the audio .
69
70     @type  src_path: string
71     @param src_path: source file path , with extension
72
73     @rtype:    tuple , int
74     @return:   shape , sample_rate
75     """
76     # Open the audio file
77     # sample_rate , audio_array = wavfile.read(src_path)
78     audio_array , sample_rate = sf.read(src_path , dtype='int16')
79     shape = audio_array.shape

```

```

80
81     # Convert the audio_array to binary format and flatten the array
82     bits = np.unpackbits(audio_array.astype(np.int16).view(np.uint8))
83
84     # Store the binary bits
85     self._digital_data = bits
86     # Store the analogue data
87     self._analogue_data = audio_array
88
89     return shape, sample_rate
90
91
92     # def read_mp3(self, src_path):
93     """
94     #     Read the mp3 file,
95     #     store the audio information as binary bits in _digital_data,
96     #     store the audio information as ndarray in _analogue_data.
97     #     Return the frame_rate, sample_width, channels of the audio.
98
99     #         @type src_path: string
100    #         @param src_path: source file path, with extension
101
102   #         @rtype: tuple
103   #         @return: frame rate, sample width, channels
104   """
105
106   # Open the audio file
107   # audio = AudioSegment.from_file(src_path, format="mp3")
108   # frame_rate, sample_width, channels = audio.frame_rate, audio.
109   # sample_width, audio.channels
110
111   # Convert the audio to a NumPy array
112   # audio_array = np.array(audio.get_array_of_samples())
113   # print(audio_array.dtype)
114
115   # Get the shape of the array: e.g. (2392270,)
116   # shape = audio_array.shape
117
118   # Convert the audio_array to binary format and flatten the array
119   # bits = np.unpackbits(audio_array.astype(np.uint8))
120
121   # Store the binary bits
122   # self._digital_data = bits
123   # Store the analogue data
124   # self._analogue_data = audio_array
125
126
127   def get_digital_data(self):
128       """
129       Get the bits to be transmitted
130
131       @rtype: ndarray

```

```

133             @return: data bits
134             """
135         return self._digital_data
136
137     def get_analogue_data(self):
138         """
139             Get the analogue data to be transmitted
140
141             @rtype: ndarray
142             @return: analogue data
143         """
144
145         return self._analogue_data
146
147
148 if __name__ == '__main__':
149     # test
150     source = Source()
151     source.read_txt("Resource/hardcoded.txt")
152     text_bits = source.get_digital_data()
153     print(text_bits)
154     print(type(text_bits))
155
156     source.read_png("Resource/image.png")
157     image_bits = source.get_digital_data()
158     print(image_bits[:16])
159     image_pixels = source.get_analogue_data()
160     print(image_pixels[0][0][:2])
161
162     # frame_rate, sample_width, channels = source.read_mp3("Resource/
163     # file_example_MP3_1MG.mp3")
164     # print(frame_rate, sample_width, channels)
165     # audio_bits = source.get_digital_data()
166     # print(audio_bits[:16])
167     # audio_array = source.get_analogue_data()
168     # print(audio_array[:2])
169
170     shape, sample_rate = source.read_wav("Resource/file_example_WAV_1MG.wav")
171     print(' ')
172     print(shape, sample_rate)
173     audio_bits = source.get_digital_data()
174     print(audio_bits[:16])
175     audio_array = source.get_analogue_data()
176     print(audio_array[0])

```

6.2 Channel

```

1 # Copyright (c) 2023 Chenye Yang
2
3 import numpy as np
4 import logging
5
6 # Create a logger in this module

```

```

7     logger = logging.getLogger(__name__)
8
9
10
11    def create_parity_check_matrix(G):
12        """
13            Create the parity-check matrix,  $H = [I_{n-k} \mid P.T]$ 
14
15            @type G: ndarray
16            @param G: generator matrix in systematic form,  $G = [P \mid I_k]$ 
17
18            @rtype: ndarray
19            @return: parity-check matrix
20        """
21
22        # Get the size of the generator matrix
23        k, n = G.shape
24
25        # Create the parity-check matrix
26        #  $G = [P \mid I_k]$ , Extract P
27        P = G[:, :n-k]
28
29        #  $H = [I_{n-k} \mid P.T]$ 
30        H = np.hstack((np.eye(n-k, dtype=np.uint8), P.T))
31
32    return H
33
34
35    def create_syndrome_table(H):
36        """
37            Create a table of all possible syndromes and their corresponding error
38            vectors (syndrome look-up table)
39
40            @type H: ndarray
41            @param H: parity-check matrix
42        """
43
44        # Get the size of the parity-check matrix
45        _, n = H.shape
46
47        # Create a table of all possible syndromes and their corresponding error
48        # vectors (syndrome look-up table)
49        coset_leader = np.vstack((np.zeros(n, dtype=np.uint8), np.eye(n, dtype=np.
50                                  uint8)))
51        possible_syndromes = (coset_leader @ H.T) % 2
52        syndrome_table = {str(possible_syndromes[i]) : coset_leader[i] for i in
53                          range(n+1)}
54
55    return syndrome_table
56
57
58    class Linear_Code:
59        """
60            (7, 4) Systematic Linear Block (Hamming) Code
61        """

```

```

57     def __init__(self):
58         self.n, self.k = 7, 4
59         self.G = np.array([[1, 1, 0, 1, 0, 0, 0],
60                            [0, 1, 1, 0, 1, 0, 0],
61                            [1, 1, 1, 0, 0, 1, 0],
62                            [1, 0, 1, 0, 0, 0, 1]], dtype=np.uint8)
63         self.H = np.array([[1, 0, 0, 1, 0, 1, 1],
64                            [0, 1, 0, 1, 1, 1, 0],
65                            [0, 0, 1, 0, 1, 1, 1]], dtype=np.uint8)
66         self.syndrome_table = {'[0_0_0]': np.array([0, 0, 0, 0, 0, 0, 0]),
67                               '[1_0_0]': np.array([1, 0, 0, 0, 0, 0, 0]),
68                               '[0_1_0]': np.array([0, 1, 0, 0, 0, 0, 0]),
69                               '[0_0_1]': np.array([0, 0, 1, 0, 0, 0, 0]),
70                               '[1_1_0]': np.array([0, 0, 0, 1, 0, 0, 0]),
71                               '[0_1_1]': np.array([0, 0, 0, 0, 1, 0, 0]),
72                               '[1_1_1]': np.array([0, 0, 0, 0, 0, 1, 0]),
73                               '[1_0_1]': np.array([0, 0, 0, 0, 0, 0, 1])}
74
75     def encoder_systematic(self, bits):
76         """
77             Systematic – Encode the to-be-transmitted binary bits message with
78             (7,4) hamming encoder, return the to-be-transmitted codewords
79
80             @type bits: ndarray
81             @param bits: TX message
82
83             @rtype: ndarray
84             @return: TX codewords
85         """
86         encoded_array = np.zeros((len(bits) // self.k * self.n), dtype=np.
87                                  uint8)
88
89         for i in range(0, len(bits), self.k):
90             message = bits[i:i + self.k]
91             codeword = np.dot(message, self.G) % 2
92             encoded_array[i // self.k * self.n:(i // self.k + 1) * self.n] =
93                 codeword
94
95         return encoded_array
96
97     def decoder_systematic(self, encoded_array):
98         """
99             Systematic – Decode the received binary bits codeword with (7,4)
100            Hamming decoder, return the received message
101
102             @type encoded_array: ndarray
103             @param encoded_array: RX codewords
104
105             @rtype: ndarray
106             @return: RX message
107         """
108         decoded_array = np.zeros((len(encoded_array) // self.n * self.k),
109                                dtype=np.uint8)

```

```

106
107     err_count = 0
108
109     for i in range(0, len(encoded_array), self.n):
110         received_codeword = encoded_array[i:i + self.n]
111         syndrome = np.dot(self.H, received_codeword) % 2
112         if np.any(syndrome): # If there are errors, count and keep it
113             err_count += 1
114             decoded_array[i // self.n * self.k : (i // self.n + 1) * self.k] =
115                 received_codeword[self.n - self.k:self.n]
116
117             logger.info(f"Error_codeword_rate:{err_count/(len(encoded_array)//
118                         self.n)}")
119
120
121     def corrector_syndrome(self, received_array):
122         """
123             Systematic – Correct the received binary bits codeword with (7,4)
124             Hamming syndrome look-up table corrector,
125             return the estimated TX codeword = (RX codeword + error pattern)
126
127             @type received_array: ndarray
128             @param received_array: RX codewords
129
130             @rtype: ndarray
131             @return: estimated TX codewords
132         """
133
134         corrected_array = received_array.copy()
135
136         for i in range(0, len(received_array), self.n):
137             received_codeword = received_array[i:i + self.n]
138             syndrome = np.dot(self.H, received_codeword) % 2
139             if np.any(syndrome):
140                 corrected_array[i:i + self.n] = (received_codeword + self.
141                     syndrome_table[str(syndrome)]) % 2
142
143
144     class Cyclic_Code(Linear_Code):
145         """
146             (n, k) Systematic Cyclic (Hamming) Code
147
148             def __init__(self, G):
149                 self.G = G
150                 self.k, self.n = self.G.shape
151                 self.H = create_parity_check_matrix(self.G)
152
153                 self.syndrome_table = create_syndrome_table(self.H)
154

```

```

156     def corrector_lfsr(self, received_array):
157         """
158             Systematic – Correct the received binary bits codeword with (n, k)
159             Hamming LFSR corrector,
160             return the estimated TX codeword = (RX codeword + error pattern)
161
162             @type received_array: ndarray
163             @param received_array: RX codewords
164
165             @rtype: ndarray
166             @return: estimated TX codewords
167         """
168         corrected_array = received_array.copy()
169         pass
170
171     class Channel:
172         """
173             Channel
174         """
175         def binary_symmetric_channel(self, input_bits, p):
176             """
177                 BSC – binary symmetric channel with adjustable error probability
178
179                 @type input_bits: ndarray
180                 @param input_bits: TX codewords
181
182                 @type p: float
183                 @param p: error_probability
184
185                 @rtype: ndarray
186                 @return: RX codewords
187             """
188             output_bits = np.copy(input_bits)
189             for i in range(len(output_bits)):
190                 if np.random.random() < p:
191                     output_bits[i] = 1 - output_bits[i] # flip the bit
192             return output_bits
193
194
195     if __name__ == '__main__':
196         # test
197         tx_msg = np.array([0, 1, 0, 0, 1, 0, 0, 0, 0, 1, 1], dtype=np.uint8)
198         print("Original_bits:", tx_msg)
199
200     # Channel
201     channel = Channel()
202
203     # Linear Code
204     linear_code = Linear_Code()
205
206     # Encoding
207     tx_codewords = linear_code.encoder_systematic(tx_msg)

```

```

209 print("Encoded_bits : ", tx_codewords)
210
211 # Passing through the channel
212 rx_codewords = channel.binary_symmetric_channel(tx_codewords, 0.1)
213 print("Bits_after_channel:", rx_codewords)
214
215 # Correction with syndrome look-up table
216 estimated_tx_codewords = linear_code.corrector_syndrome(rx_codewords)
217 print("Estimated_TX_bits:", estimated_tx_codewords)
218
219 # Decoding
220 rx_msg = linear_code.decoder_systematic(estimated_tx_codewords)
221 print("Decoded_bits:", rx_msg)

```

6.3 Destination

```

1 # Copyright (c) 2023 Chenye Yang
2
3 import numpy as np
4 from PIL import Image
5 import soundfile as sf
6 # from scipy.io import wavfile
7 import logging
8
9 # Create a logger in this module
10 logger = logging.getLogger(__name__)
11
12
13 class Destination:
14     """
15         The destination
16     """
17
18     def set_digital_data(self, bits):
19         """
20             Record the received digital data
21
22             @type bits: ndarray
23             @param bits: data bits
24         """
25         self._digital_data = bits
26
27
28     def set_analogue_data(self, array):
29         """
30             Record the received analogue data
31
32             @type array: ndarray
33             @param array: analogue data array
34         """
35         self._analogue_data = array
36
37

```

```

38     def get_digital_data(self):
39         """
40             Get the received digital data
41
42                 @rtype: ndarray
43                 @return: data bits
44         """
45         return self._digital_data
46
47
48     def get_analogue_data(self):
49         """
50             Get the received analogue data
51
52                 @rtype: ndarray
53                 @return: analogue data
54         """
55         return self._analogue_data
56
57
58     def write_txt(self, dest_path):
59         """
60             Write data to a text file
61
62                 @type dest_path: string
63                 @param dest_path: destination file path, with extension
64         """
65         byte_array = bytearray(np.packbits(self._digital_data).tobytes())
66         with open(dest_path, 'wb') as file:
67             file.write(byte_array)
68
69
70     def write_png_from_digital(self, dest_path, height, width, channels):
71         """
72             Write color information in bits array to a png file, at the same time
73             store the color information as ndarray in _analogue_data
74
75                 @type dest_path: string
76                 @param dest_path: destination file path, with extension
77
78                 @type height: int
79                 @param height: height of the image
80
81                 @type width: int
82                 @param width: width of the image
83
84                 @type channels: int
85                 @param channels: channels of the image
86         """
87         # Convert the bit array to uint8 array
88         uint8_array = np.packbits(self._digital_data)
89
90         # Reshape the array to a 3D array of pixels (height, width, channels)
91         pixels = uint8_array.reshape(height, width, channels)

```

```

91
92     # Store the analogue data
93     self._analogue_data = pixels
94
95     # Create a new image from the pixel values
96     new_image = Image.fromarray(pixels)
97
98     # Save the new image to a file
99     new_image.save(dest_path)
100
101
102 def write_png_from_analogue(self, dest_path):
103     """
104         Write color information in (height, width, channels) array to a png
105         file, at the same time store the color information as bit array in
106         _digital_data
107
108         @type dest_path: string
109         @param dest_path: destination file path, with extension
110     """
111
112     # Create a new image from the pixel values
113     new_image = Image.fromarray(self._analogue_data)
114
115     # Save the new image to a file
116     new_image.save(dest_path)
117
118     # Convert the img_array to binary format and flatten the array
119     bits = np.unpackbits(self._analogue_data.astype(np.uint8))
120
121
122 def write_wav_from_digital(self, shape, sample_rate, dest_path):
123     """
124         Write audio information in bits array to a wav file, at the same time
125         store the audio information as ndarray in _analogue_data
126
127         @type dest_path: string
128         @param dest_path: destination file path, with extension
129     """
130
131     # Convert the bit array to int16 array
132     int16_array = np.packbits(self._digital_data).view(np.int16)
133
134     # Reshape the array to a 2D array of samples (channels, samples)
135     audio_array = int16_array.reshape(shape)
136
137     # Store the analogue data
138     self._analogue_data = audio_array
139
140     # Write the array to a wav file
141     # wavfile.write(dest_path, sample_rate, audio_array)
142     sf.write(dest_path, audio_array, sample_rate)

```

```

142
143     def write_wav_from_analogue(self, sample_rate, dest_path):
144         """
145             Write audio information in audio array to a wav file, at the same time
146             store the audio information as bit array in _digital_data
147
148             @type dest_path: string
149             @param dest_path: destination file path, with extension
150             """
151
152             # Write the array to a wav file
153             # wavfile.write(dest_path, sample_rate, self._analogue_data)
154             sf.write(dest_path, self._analogue_data, sample_rate)
155
156             # Convert the audio_array to binary format and flatten the array
157             bits = np.unpackbits(self._analogue_data.astype(np.int16).view(np.
158                 uint8))
159
160             # Store the binary bits
161             self._digital_data = bits
162
163
164             # def write_mp3_from_digital(self, frame_rate, sample_width, channels,
165             # dest_path):
166             #
167             #     """
168             #     Write audio information in bits array to a mp3 file
169             #
170             #     @type dest_path: string
171             #     @param dest_path: destination file path, with extension
172             #
173             #     # Convert the bit array to uint16 array
174             #     uint16_array = np.packbits(self._digital_data).astype(np.int16)
175
176             #     # Create a new AudioSegment object from the modified audio array
177             #     modified_audio = AudioSegment(uint16_array.tobytes(), frame_rate,
178             #     sample_width, channels)
179
180             #     # Export the modified audio to a new MP3 file
181             #     modified_audio.export(dest_path, format="mp3")
182
183
184             # def write_mp3_from_analogue(self, frame_rate, sample_width, channels,
185             # dest_path):
186             #
187             #     """
188             #     Write audio information in audio array to a mp3 file
189             #
190             #     @type dest_path: string
191             #     @param dest_path: destination file path, with extension
192             #
193             #     # Create a new AudioSegment object from the modified audio array
194             #     modified_audio = AudioSegment(self._analogue_data.tobytes(),
195             #     frame_rate, sample_width, channels)
196
197             #     # Export the modified audio to a new MP3 file
198             #     modified_audio.export(dest_path, format="mp3")
199

```

```

190
191
192
193 if __name__ == '__main__':
194     # test
195     bits = np.array([0, 1, 0, 0, 1, 0, 0, 0]) # H
196     destination = Destination()
197     destination.set_data(bits)
198     destination.write_file("output.txt")

```

6.4 Utilities

```

# Copyright (c) 2023 Chenye Yang

import numpy as np
import matplotlib.pyplot as plt
from scipy.fft import fft

def plot_wav_time_domain(audio_array, sample_rate, dest_path):
    """
    Plot the audio signal in the time domain.

    @type audio_array: ndarray
    @param audio_array: audio data array

    @type sample_rate: int
    @param sample_rate: sample rate of the audio

    @type dest_path: string
    @param dest_path: destination file path, with extension
    """

    # Copy the audio array
    data = audio_array.copy()
    # Normalize to [-1, 1]
    data = data / np.max(np.abs(data), axis=0)

    times = np.arange(len(data))/float(sample_rate)

    # Prepare the subplots
    fig, axs = plt.subplots(1, 2, figsize=(15, 4))

    # Time domain representation for channel 1
    axs[0].fill_between(times, data[:, 0], color='k')
    axs[0].set_xlim(times[0], times[-1])
    axs[0].set_xlabel('time_(s)')
    axs[0].set_ylabel('amplitude')
    axs[0].set_title('Time-Domain-Representation--Channel1')

    # Time domain representation for channel 2
    axs[1].fill_between(times, data[:, 1], color='k')
    axs[1].set_xlim(times[0], times[-1])
    axs[1].set_xlabel('time_(s)')

```

```

42     axs[1].set_ylabel('amplitude')
43     axs[1].set_title('Time-Domain-Representation--Channel_2')
44
45     # Display the plot
46     plt.tight_layout()
47     plt.savefig(dest_path, dpi=300)
48     plt.close()
49
50
51 def plot_wav_frequency_domain(audio_array, sample_rate, dest_path):
52     """
53         Plot the audio signal in the frequency domain.
54
55         @type audio_array: ndarray
56         @param audio_array: audio data array
57
58         @type sample_rate: int
59         @param sample_rate: sample rate of the audio
60
61         @type dest_path: string
62         @param dest_path: destination file path, with extension
63     """
64     # Copy the audio array
65     data = audio_array.copy()
66     # Normalize to [-1, 1]
67     data = data / np.max(np.abs(data), axis=0)
68
69     # Prepare the subplots
70     fig, axs = plt.subplots(1, 2, figsize=(15, 4))
71
72     # Frequency domain representation for channel 1
73     fft_out_channel_1 = fft(data[:, 0])
74     magnitude_spectrum_channel_1 = np.abs(fft_out_channel_1)
75     frequencies_channel_1 = np.linspace(0, sample_rate, len(
76                                         magnitude_spectrum_channel_1))
77
77     axs[0].plot(frequencies_channel_1[:int(len(frequencies_channel_1)/2)],
78                 magnitude_spectrum_channel_1[:int(len(magnitude_spectrum_channel_1)/2)])
79     # plot only first half of frequencies
80     axs[0].set_xlabel('frequency_(Hz)')
81     axs[0].set_ylabel('magnitude')
82     axs[0].set_title('Frequency-Domain-Representation--Channel_1')
83
84     # Frequency domain representation for channel 2
85     fft_out_channel_2 = fft(data[:, 1])
86     magnitude_spectrum_channel_2 = np.abs(fft_out_channel_2)
87     frequencies_channel_2 = np.linspace(0, sample_rate, len(
88                                         magnitude_spectrum_channel_2))
89
89     axs[1].plot(frequencies_channel_2[:int(len(frequencies_channel_2)/2)],
90                 magnitude_spectrum_channel_2[:int(len(magnitude_spectrum_channel_2)/2)])
91     # plot only first half of frequencies
92     axs[1].set_xlabel('frequency_(Hz)')
93     axs[1].set_ylabel('magnitude')

```

```

90     axs[1].set_title('Frequency-Domain-Representation---Channel-2')
91
92     # Display the plot
93     plt.tight_layout()
94     plt.savefig(dest_path, dpi=300)
95     plt.close()

```

```

1  # Copyright (c) 2023 Pranav Kharche, Chenye Yang
2  # Toolbox for polynomials and CRC
3
4  import numpy as np
5  import logging
6
7  # Create a logger in this module
8  logger = logging.getLogger(__name__)
9
10
11 def order(p):
12     p = p >> 1
13     order = 0
14     while p:
15         p = p >> 1
16         order += 1
17     return order
18
19 def bitRev(p, pOrder = None):
20     if p == 0:
21         return 0
22     if pOrder == None:
23         pOrder = order(p)
24
25     retVal = 0
26     for i in range(pOrder+1):
27         retVal = (retVal << 1) + (p %2)
28         p = p >>1
29     return retVal
30
31 def polyDiv(dividend, divisor, dividendOrder = None, divisorOrder = None):
32     if dividendOrder == None or divisorOrder == None:
33         dividendOrder = order(dividend)
34         divisorOrder = order(divisor)
35
36     sizeDiff = dividendOrder - divisorOrder
37     rem = dividend
38     remOrder = dividendOrder
39     result = 0
40     for i in range(sizeDiff, -1, -1):
41         if(rem >> remOrder):
42             rem = rem ^ (divisor << i)
43             result = result + (1 << i)
44             remOrder -= 1
45
46     # if rem:

```

```

47     #     print(f'{dividend:b}', ' : ', f'{divisor:b}', ' = ', f'{result
48     #:b}', ' R', f'{rem:0{divisorOrder}b}', sep=''))
49     # else:
50     #     print(f'{dividend:b}', ':', f'{divisor:b}', '=', f'{result:b
51     }')
52     return result, rem
53
54 def findGen(n,k):
55     target = (1 << n) + 1
56     gen = (1 << (n-k)) + 3
57     parity, rem = polyDiv(target, gen, n, n-k)
58     while rem:
59         gen += 2
60         if gen >= target:
61             return None, None
62         parity, rem = polyDiv(target, gen, n, n-k)
63     logger.debug('generator =', f'{gen:b}')
64     logger.debug('parity =', f'{parity:b}')
65     return gen, parity
66
67 def buildMatrix(n, k, gen, parity):
68     genMatrix = [gen]
69     # print(f'{gen:0{n}b}')
70     for i in range(k-1):
71         nextLine = genMatrix[i] << 1
72         if (nextLine >> (n-k))%2:
73             nextLine = nextLine ^ gen
74         genMatrix.append(nextLine)
75         # print(f'{nextLine:0{n}b}')
76     logger.debug('Generator matrix')
77     for i in range(k):
78         genMatrix[i] = bitRev(genMatrix[i], n-1)
79     logger.debug(f'{genMatrix[i]:0{n}b}')
80     return genMatrix
81
82 def findMatrix(n,k):
83     gen, parity = findGen(n,k)
84     if gen == None:
85         return None
86     return buildMatrix(n, k, gen, parity)
87
88 def encode(data, gen):
89     if order(data)+1 > len(gen):
90         return None
91     result = 0
92     data = bitRev(data, len(gen)-1)
93     for row in gen:
94         result = result ^ ((data & 1)*row)
95         data = data >> 1
96     return result
97
98 def genMatrixDecmial2Ndarray(genMatrix_decimal, n):
99     """

```

```

99     Convert the generator matrix in decimal form to numpy array form
100
101     @type  genMatrix_decimal: list
102     @param genMatrix_decimal: generator matrix in decimal form
103
104     @type  n: int
105     @param n: number of bits in a codeword
106
107     @rtype:   ndarray
108     @return:  generator matrix in numpy array form
109     """
110
111     # Convert the generator matrix in decimal form to binary form
112     genMatrix_binary = [[int(bit) for bit in f'{num:0{n}b}'] for num in
113                         genMatrix_decimal]
114
115     # Convert the binary generator matrix to a numpy array
116     G = np.array(genMatrix_binary, dtype=np.uint8)
117
118     return G

```

6.5 Linear code

```

1  # Copyright (c) 2023 Chenye Yang
2
3 import logging
4
5 from Source import source
6 from Channel import channel
7 from Destination import destination
8 from Utils import plot_wav
9
10
11 # Configure the logging
12 logging.basicConfig(level=logging.INFO, format='%(asctime)s - %(name)s - %(levelname)s - %(message)s')
13
14 # Create a logger in the main module
15 logger = logging.getLogger(__name__)
16
17
18 def linear_txt():
19     """
20         Source - Channel encoder - Channel - Channel decoder - Destination
21
22         txt      - (7,4) linear      - bsc      - (7,4) linear      - txt
23     """
24
25     src = source.Source()
26     chl = channel.Channel()
27     linear_code = channel.Linear_Code()
28     dest = destination.Destination()
29
30

```

```

31     src.read_txt("Resource/hardcoded.txt")
32     tx_msg = src.get_digital_data()
33
34     tx_codeword = linear_code.encoder_systematic(tx_msg)
35
36     rx_codeword = chl.binary_symmetric_channel(tx_codeword, 0.01)
37
38     # without error correction
39     rx_msg = linear_code.decoder_systematic(rx_codeword)
40     dest.set_digital_data(rx_msg)
41     dest.write_txt("Result/linear-bsc-output.txt")
42
43     # with error correction
44     estimated_tx_codeword = linear_code.corrector_syndrome(rx_codeword)
45     rx_msg = linear_code.decoder_systematic(estimated_tx_codeword)
46     dest.set_digital_data(rx_msg)
47     dest.write_txt("Result/linear-bsc-output-syndrome-corrected.txt")
48
49
50 def linear_png():
51     """
52         Source - Channel encoder - Channel - Channel decoder - Destination
53
54         png      - (7,4) linear      - bsc      - (7,4) linear      - png
55     """
56     src = source.Source()
57     chl = channel.Channel()
58     linear_code = channel.Linear_Code()
59     dest = destination.Destination()
60
61
62     height, width, channels = src.read_png("Resource/image.png")
63     tx_msg = src.get_digital_data()
64
65     tx_codeword = linear_code.encoder_systematic(tx_msg)
66
67     rx_codeword = chl.binary_symmetric_channel(tx_codeword, 0.01)
68
69     # without error correction
70     rx_msg = linear_code.decoder_systematic(rx_codeword)
71     dest.set_digital_data(rx_msg)
72     dest.write_png_from_digital("Result/linear-bsc-output.png", height, width,
73                               channels)
74
75     # with error correction
76     estimated_tx_codeword = linear_code.corrector_syndrome(rx_codeword)
77     rx_msg = linear_code.decoder_systematic(estimated_tx_codeword)
78     dest.set_digital_data(rx_msg)
79     dest.write_png_from_digital("Result/linear-bsc-output-syndrome-corrected.
80                               png", height, width, channels)
81
82 def linear_wav():
83     """

```

```

83     Source - Channel encoder - Channel - Channel decoder - Destination
84
85     wav      = (7,4) linear      - bsc      = (7,4) linear      - wav
86
87     src = source.Source()
88     chl = channel.Channel()
89     linear_code = channel.Linear_Code()
90     dest = destination.Destination()
91
92
93     shape, sample_rate = src.read_wav("Resource/file_example_WAV_1MG.wav")
94     plot_wav.plot_wav_time_domain(src.get_analogue_data(), sample_rate, "
95         Result/wav-time-domain-TX.png")
96     plot_wav.plot_wav_frequency_domain(src.get_analogue_data(), sample_rate, "
97         Result/wav-frequency-domain-TX.png")
98
99     # tx_msg = src.get_analogue_data()
100    # rx_msg = tx_msg
101    # dest.set_analogue_data(rx_msg)
102    # plot_wav.plot_wav_time_domain(dest.get_analogue_data(), sample_rate, "
103        Result/wav-time-domain-RX.png")
104    # plot_wav.plot_wav_frequency_domain(dest.get_analogue_data(), sample_rate,
105        "Result/wav-frequency-domain-RX.png")
106    # dest.write_wav_from_analogue(sample_rate, "Result/hamming-bsc-output.wav"
107        ")
108
109
110    tx_msg = src.get_digital_data()
111
112    tx_codeword = linear_code.encoder_systematic(tx_msg)
113
114    rx_codeword = chl.binary_symmetric_channel(tx_codeword, 0.01)
115
116    # without error correction
117    rx_msg = linear_code.decoder_systematic(rx_codeword)
118
119    dest.set_digital_data(rx_msg)
120    dest.write_wav_from_digital(shape, sample_rate, "Result/linear-bsc-output."
121        wav")
122
123
124    plot_wav.plot_wav_time_domain(dest.get_analogue_data(), sample_rate, "
125        Result/linear-bsc-wav-time-domain-RX.png")
126    plot_wav.plot_wav_frequency_domain(dest.get_analogue_data(), sample_rate,
127        "Result/linear-bsc-wav-frequency-domain-RX.png")
128
129
130    # with error correction
131    estimated_tx_codeword = linear_code.corrector_syndrome(rx_codeword)
132    rx_msg = linear_code.decoder_systematic(estimated_tx_codeword)
133
134    dest.set_digital_data(rx_msg)
135    dest.write_wav_from_digital(shape, sample_rate, "Result/linear-bsc-output-
136        syndrome-corrected.wav")

```

```

127     plot_wav.plot_wav_time_domain(dest.get_analogue_data(), sample_rate, "
128         Result/linear-bsc-wav-time-domain-RX-syndrome-corrected.png")
129     plot_wav.plot_wav_frequency_domain(dest.get_analogue_data(), sample_rate,
130         "Result/linear-bsc-wav-frequency-domain-RX-syndrome-corrected.png")
131
132 if __name__ == '__main__':
133     linear_txt()
134     linear_png()
135     linear_wav()

```

6.6 Cyclic code

```

1 # Copyright (c) 2023 Chenye Yang
2
3 import logging
4
5 from Source import source
6 from Channel import channel
7 from Destination import destination
8 from Utils import plot_wav, polyTools
9
10
11 # Configure the logging
12 logging.basicConfig(level=logging.INFO, format='%(asctime)s - %(name)s - %(levelname)s - %(message)s')
13
14 # Create a logger in the main module
15 logger = logging.getLogger(__name__)
16
17
18
19 # Work with (3, 1) cyclic code
20 n = 3
21 k = 1
22
23 # Create the generator matrix
24 genMatrix_decimal = polyTools.findMatrix(n, k)
25 G = polyTools.genMatrixDecmial2Ndarray(genMatrix_decimal, n)
26
27
28 def cyclic_txt():
29     """
30         Source - Channel encoder - Channel - Channel decoder - Destination
31
32         txt      - (n, k) cyclic      - bsc      - (n, k) cyclic      - txt
33     """
34     src = source.Source()
35     chl = channel.Channel()
36     cyclic_code = channel.Cyclic_Code(G)
37     dest = destination.Destination()
38
39

```

```

40     src.read_txt("Resource/hardcoded.txt")
41     tx_msg = src.get_digital_data()
42
43     tx_codeword = cyclic_code.encoder_systematic(tx_msg)
44
45     rx_codeword = chl.binary_symmetric_channel(tx_codeword, 0.01)
46
47     # without error correction
48     rx_msg = cyclic_code.decoder_systematic(rx_codeword)
49     dest.set_digital_data(rx_msg)
50     dest.write_txt("Result/cyclic-bsc-output.txt")
51
52     # with error correction
53     estimated_tx_codeword = cyclic_code.corrector_syndrome(rx_codeword)
54     rx_msg = cyclic_code.decoder_systematic(estimated_tx_codeword)
55     dest.set_digital_data(rx_msg)
56     dest.write_txt("Result/cyclic-bsc-output-syndrome-corrected.txt")
57
58
59 def cyclic_png():
60     """
61     Source - Channel encoder - Channel - Channel decoder - Destination
62
63     png      - (n, k) cyclic      - bsc      - (n, k) cyclic      - png
64     """
65     src = source.Source()
66     chl = channel.Channel()
67     cyclic_code = channel.Cyclic_Code(G)
68     dest = destination.Destination()
69
70
71     height, width, channels = src.read_png("Resource/image.png")
72     tx_msg = src.get_digital_data()
73
74     tx_codeword = cyclic_code.encoder_systematic(tx_msg)
75
76     rx_codeword = chl.binary_symmetric_channel(tx_codeword, 0.01)
77
78     # without error correction
79     rx_msg = cyclic_code.decoder_systematic(rx_codeword)
80     dest.set_digital_data(rx_msg)
81     dest.write_png_from_digital("Result/cyclic-bsc-output.png", height, width,
82                               channels)
83
84     # with error correction
85     estimated_tx_codeword = cyclic_code.corrector_syndrome(rx_codeword)
86     rx_msg = cyclic_code.decoder_systematic(estimated_tx_codeword)
87     dest.set_digital_data(rx_msg)
88     dest.write_png_from_digital("Result/cyclic-bsc-output-syndrome-corrected.
89                               png", height, width, channels)
90
91
92 def cyclic_wav():
93     """

```

```

92     Source - Channel encoder - Channel - Channel decoder - Destination
93
94     wav      - (n,k) cyclic      - bsc      - (n,k) cyclic      - wav
95     """
96     src = source.Source()
97     chl = channel.Channel()
98     cyclic_code = channel.Cyclic_Code(G)
99     dest = destination.Destination()
100
101
102    shape, sample_rate = src.read_wav("Resource/file-example_WAV_1MG.wav")
103    plot_wav.plot_wav_time_domain(src.get_analogue_data(), sample_rate, "
104        Result/wav-time-domain-TX.png")
105    plot_wav.plot_wav_frequency_domain(src.get_analogue_data(), sample_rate, "
106        Result/wav-frequency-domain-TX.png")
107
108    # tx-msg = src.get_analogue_data()
109    # rx-msg = tx-msg
110    # dest.set_analogue_data(rx-msg)
111    # plot_wav.plot_wav_time_domain(dest.get_analogue_data(), sample_rate, "
112        Result/wav-time-domain-RX.png")
113    # plot_wav.plot_wav_frequency_domain(dest.get_analogue_data(), sample_rate,
114        , "Result/wav-frequency-domain-RX.png")
115    # dest.write_wav_from_analogue(sample_rate, "Result/hamming-bsc-output.wav"
116        )
117
118
119    tx_msg = src.get_digital_data()
120
121    tx_codeword = cyclic_code.encoder_systematic(tx_msg)
122
123    rx_codeword = chl.binary_symmetric_channel(tx_codeword, 0.01)
124
125    # without error correction
126    rx_msg = cyclic_code.decoder_systematic(rx_codeword)
127
128    dest.set_digital_data(rx_msg)
129    dest.write_wav_from_digital(shape, sample_rate, "Result/cyclic-bsc-output."
130        wav")
131
132
133    plot_wav.plot_wav_time_domain(dest.get_analogue_data(), sample_rate, "
134        Result/cyclic-bsc-wav-time-domain-RX.png")
135    plot_wav.plot_wav_frequency_domain(dest.get_analogue_data(), sample_rate,
136        "Result/cyclic-bsc-wav-frequency-domain-RX.png")
137
138
139    # with error correction
140    estimated_tx_codeword = cyclic_code.corrector_syndrome(rx_codeword)
141    rx_msg = cyclic_code.decoder_systematic(estimated_tx_codeword)
142
143    dest.set_digital_data(rx_msg)
144    dest.write_wav_from_digital(shape, sample_rate, "Result/cyclic-bsc-output-
145        syndrome-corrected.wav")

```

```
136     plot_wav.plot_wav_time_domain(dest.get_analogue_data(), sample_rate, "
137         Result/cyclic-bsc-wav-time-domain-RX-syndrome-corrected.png")
138     plot_wav.plot_wav_frequency_domain(dest.get_analogue_data(), sample_rate,
139         "Result/cyclic-bsc-wav-frequency-domain-RX-syndrome-corrected.png")
140
141 if __name__ == '__main__':
142     cyclic_txt()
143     cyclic_png()
144     cyclic_wav()
```